



TRACKMAN PERFORMANCE STUDIO

QUICK START GUIDE




Table of Contents

1. Starting a New Practice Session
2. Navigating Shot Analysis Mode
3. Creating a New TrackMan Account
4. Exporting Your Data
5. Using the Swing Cameras
6. Navigating Game Modes
7. Adjusting Settings Before Starting a Course
8. Playing Online With Friends
9. Simple Troubleshooting You Can Do Yourself



I. Starting a New Practice Session


1. Choose Shot Analysis for detailed swing data, or Range Mode for a more driving-range style layout.
2. Select your club type.
3. Place the ball in the centre of the hitting mat
4. Start swinging – your data will appear instantly on screen.



💡 *Pro Tip:*

Shot Analysis Mode allows rapid succession shots. You can hit the next ball immediately after contact.

Range Mode requires the previous ball to stop rolling before it registers the next shot.



2. Navigating Shot Analysis Mode

- Ball Data – Carry, total, launch angle, spin, ball speed.
- Club Data – Club speed, attack angle, club path, face angle, smash factor.
- Ball Flight Screen – A 3D replay of your ball flight.
- Numbers Table – All metrics in chart form for easy comparison.
- Video – View the Swing Camera! Use AI analysis to fix your swing.
- **Compare Mode – Compare you swing with a Pro’s Swing!**

Use the icons at the top corner of the window to toggle modes.



3. Creating a New TrackMan Account

1. Tap Login on the main menu or scan the QR code at the top corner
2. Select Create Account.
3. Enter your name, email, and password.
4. Confirm your account via the email you'll receive.
5. Log back in — now your swings will save automatically to your MyTrackMan app.

Why log in?

Your swings and rounds will sync to your TrackMan profile. You can review them anytime on your phone or laptop.

SCAN ME!



**TARGET
ACTICE**

**PUTTING
ANALYSIS**

ENTRY SPEED DISTANCE

12'3"

CARRY	TOTAL	CURVE	CLUB SPEED	BALL SPEED	SMASH FAC.	SPIN RATE	ATTACK ANG.	CLUB PATH	FACE TO PATH
102.9	106.7	2R	75.4	84.9	1.13	8744	-3.8	-1.4	2.9
105.1 yds	+5.8 113.6 yds	+7.8 ft	+16 75.1 mph	+1.5 85.9 mph	+3.8 1.14	+0.05 7912 rpm	+18.38 -2.4 deg	+1.9 0.2 deg	+1.8 -0.3 deg



4. Exporting Your Data

- Go to Menu → Session → Export.
- Choose:
 - Email Export – type your email, receive a PDF/CSV file.
- If you have logged in with your Trackman account, the data will be automatically saved to your account!

5. Using the Swing Cameras (Shot Analysis mode ONLY !)



- Tap Video on the right-hand menu (the 4 squares icon)
- Choose Down-the-line or Face-on camera.
- After your shot:
 - Play back in slow motion.
 - Use drawing tools for swing plane lines. You can adjust visibility of lines using the green sparkle icon

The screenshot displays the Shot Analysis app interface. The top navigation bar includes icons for Exit, Library, Shortcuts, and SHOT ANALYSIS. The main content area is split into two video views of a golfer's swing, both labeled 'LIVE' and 'See3CAM_24CUG'. The left view shows a side profile of the golfer with red lines tracing the club's path. The right view shows a front-facing view of the golfer with red lines tracing the club's path. A central menu lists 'DYNAMIC' and 'STATIC' analysis options. The bottom dashboard displays key performance indicators (KPIs) for the shot.

CARRY	TOTAL	CLUB SPEED	SMASH FAC.	CLUB PATH	FACE ANG.
177.0	183.6	97.0	1.36	2.7	3.1
142.5 m ±20.2	153.0 m ±19.6	87.8 mph ±6.0	1.26 ±0.06	5.5 deg ±2.5	0.7 deg ±2.3



6. Navigating Game Modes

From the main menu, select Games.

You'll see options like:

- Bullseye – Score points by hitting targets on screen.
- Closest to the Pin – Compete to see who lands nearest the flag.
- Capture the Flag – A multiplayer target game where flags are “captured” by hitting shots closer than your opponents.
- Long Drive – Test who can hit the farthest drive.

 *Pro Tip: Games are a fun way to warm up or play with friends in groups. Scores are automatically tracked on screen.*

**CATCH THE CUTE
MONSTERS IN
MAGIC POND**

7. Adjusting Settings Before Starting a Course

1. From the main menu, tap ALL, then Courses
2. Pick a course, add players, and select your tee box.
3. Adjust Settings on the right side:
 - Wind & Weather – Calm, breezy, or match real-world conditions.
 - Putting Mode – Auto-putt, gimmes (select distance), or full putting. Make sure you change this prior to starting your round! You cannot change this mid-round.
 - Pin Position & Green Speed – Make greens easier or more challenging.
4. Confirm players, order, and hit Start Round.

 *Pro Tip: Can't finish your round? If you have a Trackman account, you can always just resume where you left off by clicking "My Activities" in the top left corner of the main menu*

QUICK LOGIN

Scan QR or use PIN 791815
with Trackman Golf App



La Romana, Dominican Republic

CASA DE CAMPO 'TEETH OF THE DOG'

Par 72 (6969 yds) | Difficulty: ●●●●○

SETTINGS

Game type: Stroke (Net)

Putting: Auto - Tour Pro

Holes: All

Pins: Easy

Wind: Calm

GAME SETTINGS

this to get detected.




8. Playing Online With Friends

TrackMan allows you to play online golf rounds with friends anywhere in the world.

1. Make sure you are logged in to your TrackMan account.
2. From the main menu, go to Virtual Golf → Online Mode.
3. Choose a course and format (stroke play, match play, etc.).
4. Invite your friends:
 - Select them from your TrackMan friend list (connected via the MyTrackMan app).
 - Or share an invite code.
5. Once they accept, you'll all appear in the same round – each person plays from their own simulator location.

✓ Pro Tip: Online play works best if everyone agrees on putting mode (auto-putt vs full putting) before starting.





Simple Troubleshooting You Can Do Yourself

If things aren't working as expected, try these easy fixes:

No Ball Readings?

Make sure the ball is in the hitting zone.
Wipe the ball clean.

Screen Frozen or Program Error?

Close the program (Press Alt+F4).
Reopen TrackMan Performance Studio (orange TPS icon) from the desktop.

Numbers Look Wrong?

Confirm the correct club is selected.
Confirm you are using a white ball with no markings or dots

Still Having Issues?

Restart the PC and relaunch TrackMan Performance Studio.
If the issue continues, scan the Troubleshooting QR Code located beside each monitor station and fill the form

All guests will be compensated for any inconvenience! Customer service and satisfaction is our top priority at Shotgun Indoor Golf. Thank you for joining us at our facility and happy golfing!